

Faster, Safer, Simpler  
...and Smaller!

**LINIAN**   
FASTER. SAFER. SIMPLER.

18TH  
EDITION  
COMPLIANT

# NEW NANOCLIP™

For fibre cables  
and all other small  
diameter cables.

To fit: 2mm and 3mm  
diameter cables.

Available in:



 **MADE IN  
BRITAIN**

## HOW TO INSTALL

### DRILL HOLE

Drill a hole in your substrate.  
We suggest a Ø3mm hole  
at a depth of 16mm.



### INSERT THE CABLE

Insert the cable into  
the open side of the clip.  
Make sure it stays seated  
in the side with the opening.



### PUSH IT IN

Push it into the wall.  
Insert with the closed area  
of the clip facing into the wall.

